

STEP 1: BEFORE
 AIR-PUNCH
 DOWN

FIG. 1A


STEP 2: AIR-PUNCH
 DOWN TO LOCATE
 MASKING TAPE
 IN POSITION

FIG. 1B

STEP 3: AIR BLOW ACTIVATED
 MASKING TAPE SEPARATED
 FROM LEADFRAME

FIG. 1C





STEP 1: AIR-PURGE
DOWN AND FINGER WEDGE
INSERTED INTO
MASKING TAPE

FIG. 2A

STEP 2: FINGER WEDGE
MOVES UP AND GRIP ONTO
THE MASKING TAPE

FIG. 2B

STEP 3: FINGER WEDGE SHEAR
DOWN AT SHEARING ANGLE TO
REMOVE MASKING TAPE
FROM THE LEADFRAME

FIG. 2C






FIG. 3B

FIG. 3A

